


## Instructions



# STOCKade®

## IMPULSE® ST-315i FENCING STAPLER SCHEMATIC AND PARTS



GAS POWERED, LOW VELOCITY  
PISTON TYPE FASTENING TOOL

## Charging Instructions

### Charging Instructions to charge the Ramset hex shaped battery

1. Remove the charger base and wall mount unit from the tool case. Set the charger base on a stable surface and insert the wall mount unit's plug into the back of the charger base. Plug the wall mount unit into a 120V AC outlet. A green LED indicates the charger is ready.
2. Remove the battery from the tool or case and insert terminals down into the charger. The red LED will turn on indicating the battery is charging and the green LED will turn off.


#### Note

If the battery is completely discharged, the charger will try to revive the battery by trickle charging it first. If the red and green LEDs are both flashing, the battery pack should be replaced.

3. After charging is complete, the red LED will turn off and the green LED will turn on, indicating the battery is fully charged. The charger will keep the battery at full charge until it is removed.
4. Remove the wall mount unit from the 120V AC outlet and unplug the wall mount unit from the charger base.

#### Charging times:

First charge	2 hours
Used battery	5 minutes to 2 hours



ST-315i  
Stapler

Nose Piece

Charger

Car Charger

Wall  
Charger

Batteries x2

Ear Protection

4mm  
Hex Key

Safety Glasses